

Instructions for using Opaque Paper

item# 800Q

- 1) Opaque backing material is 11" x 17" and may be cut or trimmed to best fit the image to be applied to the backing. For best performance, keep product dirt and lint free.
- 2) For application using standard heat transfer application machines, set at 375° and 40-45 lbs. pressure; on manual machines you should feel resistance when you go to close the machine. We recommend that you pre-press the garment for 3-4 seconds.
- 3) Place the opaque backing on the platen of the heat press, fabric side up. Place the printed heat transfer face down on top of the opaque backing.
- 4) Heat press for 3 seconds and remove from machine. **DO NOT PEEL TRANSFER.**
- 5) **LET COOL!**
- 6) Trim around the fused opaque backing/heat transfer to achieve the desired shape. Very sharp scissors and rotary knives do the best job, although you can use an xacto knife. Using a source of back light will make trimming easier.
- 7) Now you're ready to apply the fused opaque backing/heat transfer to the garment.
- 8) Remove paper backing protector from the opaque backing material. **BE CAREFUL... ADHESIVE IS NOW EXPOSED AND WILL STICK TOGETHER.**
- 9) Place the fused opaque backing/heat transfer in the correct position on the garment, adhesive side down. If position must be changed, lift carefully from garment and reposition.
- 10) Heat press for 6-8 seconds. **PEEL TRANSFER HOT IMMEDIATELY!**