

# EZ Press - model MP1 Mug Press Instructions

**Safe use of your mug press is your personal responsibility.  
Keep children away from the mug press at all times.  
Injury and severe burns could result.**

**NEVER** leave the mug press on and unattended.  
**NEVER** place the mug press on a wet or unstable surface.  
**NEVER** use the mug press where flammable vapors are present.  
**NEVER** touch the mug press heater as this surface becomes hot.  
**NEVER** operate the press if the power cord is frayed or damaged.  
**NEVER** place flammable objects near the mug press while operating.



## Using the digital temperature control

Press the temperature button to display temperature set point.  
While temperature is flashing, press up and down arrows to change temperature.  
Once desired temperature is flashing, push temperature button to set temperature.

## Using the digital timer

Press the timer button to display timer set point.  
While time is flashing, press up and down arrows to change time.  
Once desired time is flashing, push time button to set time.

Pushing the up arrow at any time will display the current heater temperature.

Wait for **Sby** to be displayed before placing mug in and closing handle.  
Sby = Standby mode  
Heater will not operate unless **Sby** is displayed.

**NEVER close the mug press without a mug  
inside while the press is on.  
Damage to the heater element will result.**



**RPL Supplies, Inc.**  
*"the personalization  
company"*

call  
toll free

(800) 524-0914

[www.rplsupplies.com](http://www.rplsupplies.com)

280 Midland Avenue  
Saddle Brook, NJ 07663



tel : (201) 794-8400  
fax : (201) 794-8458