



"the personalization company"

141 Lanza Ave, Bldg 3A
Garfield, NJ 07026
(800) 524-0914 (973) 767-0880
fax (973) 772-6601
www.rplsupplies.com

INSTRUCTIONS FOR CRYSTAL KEEPSAKES

1 – REMOVE FILM (CLEAR SHEET) FOR PAPER TO CRYSTAL FILM. PRINT ON SIDE THAT FILM WAS REMOVED FROM. YOU CAN CONFIRM THIS BY DAMPENING YOUR FINGER AND PRINTING ON THE STICKY SIDE.

2 – USING AN INK JET PRINTER TO THE PROPER SIZE OF THE CRYSTAL BEING USED (NO MIRROR IMAGE).

3 – ALLOW THE PRINT TO PROPERLY DRY. YOU CAN HASTEN THIS PROCESS BY USING A BLOW DRYER, OR LETTING AIR DRY FOR 5 MINUTES.

4 – CLEAN CRYSTAL TO BE USED.

5 – PLACE CRYSTAL TO PAPER PRINT (PRINTED SIDE UP) ON THE PROVIDED WORKING GLASS WHICH SHOULD NOW BE ON THE CURING MACHINE WITH THE VIEW BUTTON PRESSED AND THE LIGHT ON.

6 – USING THE FILM TO CRYSTAL GLUE DRAW THE LETTER "X" GOING FROM CORNER TO CORNER OVER THE PRINT.

7 – PLACE CLEANED CRYSTAL OVER THE PRINT AND CHECK FOR AIR BUBBLES. IF ANY AIR BUBBLES ARE NOTICED, GENTLY MOVE THE CRYSTAL AWAY FROM THE BUBBLE AND LET THE AIR EXCAPE FROM THE EDGE OF THE CRYSTAL. WHEN YOU ARE SATISFIED WITH THE CRYSTAL, SLIDE THE WORKING GLASS TOWARDS THE BACK OF THE CURING MACHINE.

8 – CLOSE THE COVER AND PRESS THE CURING 2 BUTTON. AFTER 10 SECONDS OPEN COVER AND USING A DRY CLOTH WIPE EXCESS GLUE FROM THE EDGES. CLOSE COVER TO COMPLETE THE CURING PROCESS.

9 – THE CURING MACHINE WILL BEEP WHEN THE PRESET TIME IS COMPLETED.

10 – OPEN THE COVER, REMOVE THE GLASS PLATE WITH CRYSTAL AND FILM (THAT ARE CURED)

11- CUT AWAY THE EXCESS FILM AROUND CRYSTAL (USING PROVIDED CUTTING TOOL OR SCISSORS).YOU SHOULD TRIM THE EXCESS FILM TO THE CRYSTAL EDGE.

12 - USING THE CUTTING TOOL, TRIM THE EXCESS FILM ON THE BACK OF THE CRYSTAL EDGE (THE BEVEL SHOULD BE SMOOTH). (THIS PROCESS IS LIKE CARVING WOOD TO MAKE EDGES SMOOTH). AGAIN THIS IS ON BACK OF THE CRYSTAL!

13 – WITH A DAMP CLOTH (GLASS CLEANER OPTIONAL), CLEAN ANY REMAINING GLUE. MAKE SURE THE CRYSTAL IS COMPLETELY CLEANED ON FRONT AND BACK. PLACE THE CRYSTAL FACE DOWN THIS TIME ON THE MACHINE (OPPOSITE FROM PREVIOUS CURING) AND PRESS THE CURING BUTTON.

14 – THE BACK OF THE PRINT HAS A PROTECTIVE FILM WHICH MUST BE REMOVED. THIS CAN BE ACCOMPLISHED WITH A PIECE OF TAPE BY PRESSING IT ON THE CORNER OF THE PROTECTIVE FILM MAKING SURE THERE IS A GOOD BOND, AND PULLING THE FILM OFF.

15 – CLEAN THE STAND (IF APPLICABLE) THAT WAS IN THE BOX WITH THE CRYSTAL AND PLACE IT ON THE FRONT LIGHT AREA. PUT THE CRYSTAL TO CRYSTAL GLUE IN THE AREA WHERE THE CRYSTAL WILL BE PLACED. YOU DO NOT HAVE TO USE A LOT OF GLUE FOR THIS PROCESS, BUT NOT TOO LITTLE EITHER, YOUR JUDGEMENT ON THIS WILL BE GOOD. PLACE THE CRYSTAL OVER THE STAND, MAKE SURE IT IS LOCATED WHERE YOU WANT IT. USING THE BLACK BOX THAT ACCOMPANIED THE MACHINE, PLACE IT OVER THE CRYSTAL MAKING SURE THAT THE OUTER EDGE OF THE BLACK BOX IS COMPRESSING THE RED ACTIVATION BUTTON. PRESS CURING 1 AND REMOVE AFTER THE BEEP (APPROX. 20 SECONDS).

16 – CONGRATULATIONS!!!!!!!!!!!! YOUR CRYSTAL KEEPSAKE IS COMPLETED.



"the personalization company"

141 Lanza Ave, Bldg 3A
Garfield, NJ 07026
(800) 524-0914 (973) 767-0880
fax (973) 772-6601
www.rplsupplies.com

CAUTION

DO NOT USE IN DIRECT SUNLIGHT. THE GLUE IS UV CUREABLE, AND COULD CURE BEFORE YOU ARE READY.

IF YOU DO NOT GET THE DESIRED AFFECT, AND THE GLUE HAS CURED... DO NOT GET DISTRESSED. PLACE THE CRYSTAL IN A BUCKET OF WATER FOR A FEW HOURS, REMOVE, AND CLEAN IT. OF COURSE YOU WILL HAVE TO PRINT ANOTHER PICTURE BUT YOU HAVE NOT RUINED AND EXPENSIVE PIECE OF CRYSTAL.

CRYSTAL CURING MACHINE INSTRUCTIONS

- 1) PLUG IN A/C CORD TO BACK OF UNIT
- 2) PLUG OTHER END INTO WALL RECEPTACLE
- 3) TURN MASTER SWITCH (IN BACK BY CORD) UP, TO ON POSITION
- 4) SET TIMES (UNIT WILL STORE THESE TIMES UNTIL CHANGED)

TO SET TIMES

- 1) PRESS AND RELEASE THE SET BUTTON SO THAT THE LIGHT ABOVE IT GOES ON (DISPLAY WILL GO OUT)
- 2) PRESS AND RELEASE THE CURING ONE BUTTON AND DISPLAY WILL COME BACK ON
- 3) USE UP OR DOWN BUTTON TO ADJUST TIME (ADJUST TO .20)
- 4) PRESS AND RELEASE SET BUTTON AND LIGHT ABOVE IT WILL GO OUT
- 5) PRESS AND RELEASE SET BUTTON SO THAT THE LIGHT ABOVE IT GOES ON (DISPLAY WILL GO OUT)
- 6) PRESS AND RELEASE THE CURING TWO BUTTON AND DISPLAY WILL COME BACK ON
- 7) USE UP OR DOWN BUTTON TO ADJUST TIME (ADJUST TO 1.15)
- 8) PRESS AND RELEASE SET BUTTON AND LIGHT ABOVE IT WILL GO OUT

TO USE UNIT

- 1) PRESS AND RELEASE UP BUTTON TO SEE DISPLAY FOR CURING ONE, OR DOWN TO SEE DISPLAY FOR CURING TWO
- 2) PUT CRYSTAL IN DESIRED PLACE (ONE IS IN FRONT OF UNIT, TWO IS INSIDE OF COVER)
- 3) PRESS AND RELEASE DESIRED CURING BUTTON AND TIMER WILL COUNT DOWN UNTIL BEEP AT END
- 4) REPEAT FOR OTHER CURE AS NECESSARY

TO VIEW CRYSTAL

- 1) WITH UNIT NOT RUNNING, OPEN COVER
- 2) PLACE CRYSTAL ON FRONT PORTION OF GLASS
- 3) PRESS AND RELEASE VIEW BUTTON
- 4) PRESS AGAIN TO SHUT OFF WHEN DONE